

Printing Suggestions for the
EPSON STYLUS PHOTO 2200

Jason Waltman
10 January 2003

Borderless 4x6 Prints

When attempting to make borderless 4x6 prints on the 2200 from roll paper, the printer actually enlarges your 4x6 image so it can bleed off the edge. If you'd rather be the one who decides the cut off point—rather than the printer—follow the steps below:

- Make your paper size 4.22" x 6.33"
- Fill the entire image size (no or little white space on the edges), but make sure the part that you wish to be in the final print is within the center 4x6 (see image below).
- Resize your image to 4x6 (do not crop image to 4x6, resize the entire image so the bleed border is now within the 4x6 size).
- Set 4" wide roll paper, borderless, cut sheet mode, and paper saving cut in the print dialog. The 2200 will enlarge your image when it's printed so the bleed border goes away and your image is printed as you wanted it to be.

